



NOTES:

1. ATTACH NAILER TO DECK WITH SUITABLE FASTENERS.
2. WHEN POSSIBLE, THE MECHANICAL UNITS SHOULD NOT BE SET UNTIL THE ROOF MEMBRANE AND FLASHING HAVE BEEN INSTALLED.