



NOTES:

1. THIS DETAIL SHOULD BE USED ONLY WHERE THE DECK IS SUPPORTED BY THE OUTSIDE WALL.
2. THIS DETAIL CAN BE ADAPTED TO ROOF EDGES SHOWN IN DETAIL MB-3.
3. ROOF SURFACES SHOULD BE SLOPED TO DRAIN.
4. ATTACH NAILER TO WALL WITH SUITABLE FASTENERS.
5. WOOD BLOCKING MAY BE SLOTTED FOR VENTING OF WET-FILL DECKS OR OTHER CONSTRUCTIONS WHERE APPLICABLE.
6. SCUPPER OPENING THROUGH ROOF EDGE SHOULD NOT BE LARGER THAN TWO FEET [610mm].