



NOTES:

1. THIS DETAIL TO BE USED OVER WET-FILL DECKS (E.G., LIGHTWEIGHT INSULATING CONCRETE, POURED GYPSUM) OR WHEN REROOFING OVER EXISTING WET-FILL DECKS.
2. THIS DETAIL SHOULD BE USED ONLY WHERE THE DECK IS SUPPORTED BY THE WALL.
3. WOOD BLOCKING SHOULD BE SLOTTED FOR VENTING OF WET-FILL DECKS WHERE APPLICABLE.
4. ATTACH NAILERS TO DECK WITH SUITABLE FASTENERS.
5. ALL PLYS ARE TO BE SOLIDLY MOPPED TO THE BASE SHEET. CARE SHOULD BE USED NOT TO ADHERE THE BASE SHEET TO THE WALL.
6. THE JOINTS IN THE SHEET METAL COUNTERFLASHING SHOULD NOT BE SOLDERED.
7. SEE TABLE 2 FOR ALTERNATE SHEET METAL COUNTERFLASHING TERMINATIONS.