



NOTES:

1. AN AREA DIVIDER IS DESIGNED SIMPLY AS A RAISED DOUBLE WOOD MEMBER ATTACHED TO A PROPERLY FASTENED WOOD BASE PLATE THAT IS ANCHORED TO THE ROOF DECK. AREA DIVIDERS SHOULD BE CONSIDERED TO BE LOCATED BETWEEN THE ROOF'S EXPANSION JOINTS AT 150 TO 200 FOOT [46m TO 61m] INTERVALS, DEPENDING UPON CLIMATIC CONDITIONS AND AREA PRACTICES. AREA DIVIDERS SHOULD NEVER RESTRICT THE FLOW OF WATER.
2. FLASHING REQUIREMENTS TYPICAL FOR BOTH SIDES OF AREA DIVIDER.
3. ATTACH NAILER TO DECK WITH SUITABLE FASTENERS.